


EAGLE 1225 INSTALLATION DIAGRAM FOR CONNECTING TO AT&T PANEL



NOTE:

INTRUSION FEATURE SWITCH MUST BE SET TO THE ON POSTION, TO ALLOW THE MONITORING OPERATOR TO GO TWO-WAY WITHOUT ANY INTERFERENCE FROM THE PIEZO.