

Table 18 Programmable Options

Op- tion #	Function	Default	Delete	Range	Who Can Change: U1 - Utility Access Code 1; U2 - Utility Access Code 2; M - Master;	Installer Settings
01	Panel Piezo Beeps	On	Off	On/Off	U1 U2 M	
02	Panel Voice	On	Off	On/Off	U1 U2 M	
03	Latchkey Option	Off	Off	12:00 AM- 11:59 PM	U1 U2 M	
04	Primary Phone Number	None	None	22 digits	U1	
05	Secondary Phone Number	None	None	22 digits	U1	
06	Downloader Phone Number	None	None	22 digits	U1	
07	Account Number	00000	00000	00000- 99999	U1 U2	
08	Phone Lock	Off	Off	On/Off	U1	
09	Downloader Code	12345	12345	00000- 99999	U1	
10	Entry Delay	030 sec	005 sec	005-120 sec	U1 U2	
11	Exit Delay	030 sec	005 sec	005-120 sec	U1 U2	
12	Phone Mod 1	0	0	0-3	U1	
13	Phone Mod 2	0	0	0-9	U1	
14	DTMF	On	Pulse	On/Off	U1 U2	
15	No Activity Report	Off	Off	02-24 hrs	U1 U2	
16	Auto Phone Test (Must be enabled for UL Listed systems)	Off	Off	001-254 days	U1 U2	
17	Dialer Delay	Off	Off	001-120 sec	U1 U2	
18	Alarm Cancel Report	Off	Off	001-255 min	U1 U2	
19	Supervisory Time (SUPSYNC)	12 hrs	02 hrs	02-24 hrs	U1 U2	
20	Manual Phone Test	On	Off	On/Off	U1 U2	
21	Opening Reports	Off	Off	On/Off	U1 U2	
22	Closing Reports	Off	Off	On/Off	U1 U2	
23	Force Armed Report	Off	Off	On/Off	U1 U2	
24	AC Power Failure Report (Must be enabled for UL Listed systems)	Off	Off	On/Off	U1 U2	
25	CPU Low Battery Report (Must be enabled for UL Listed systems)	On	Off	On/Off	U1 U2	
26	Fail to Communicate (Must be enabled for UL Listed systems)	On	Off	On/Off	U1 U2	

Table 18 Programmable Options

Op- tion #	Function	Default	Delete	Range	Who Can Change: U1 - Utility Access Code 1; U2 - Utility Access Code 2; M - Master;	Installer Settings
27	Ring/Hang/Ring	1	Off	1-4	U1 U2	
28	No Delay from KeyChain Touchpad	Off	Off	On/Off	U1 U2	
29	Panel Piezo Alarm	On	Off	On/Off	U1 U2	
30	Panic Alarms	On	Off	On/Off	U1 U2	
31	Day of Week	0	0	0-6	U1 U2	
32	300 Baud Central Station Communications	On	110 Baud	On/Off	U1 U2	
33	Audio Verification	Off	Off	On/Off	U1 U2	
34	Fail to Open	Off	Off	12:00 AM - 11:59 PM	U1 U2	
35	Fail to Close	Off	Off	12:00 AM - 11:59 PM	U1 U2	
36	Sensor Activated Light Lockout Start Time	Off	Off	12:00 AM - 11:59 PM	U1 U2 M	
37	Sensor Activated Light Lockout Stop Time	Off	Off	12:00 AM - 11:59 PM	U1 U2 M	
38	Auto Arm	Off	Off	On/Off	U1 U2	
39	Siren Time Out	04 min	Off	001 - 254 minutes/Off	U1 U2	
40	Trouble Beeps	On	Off	On/Off	U1 U2	
41	Chime Voice	Off	Off	On/Off	U1 U2 M	
42	Speaker Level	On	Low	On/Off	U1 U2 M	
43	Pager Phone Number	Off	Off	22 digits	U1 U2 M	
44	Pager Phone Mod 3	9	8	8 or 9	U1 U2	
45	Sensor Alarm Restoral	Off	Off	On/Off	U1 U2	
46	Fire Shutdown - AVM	Off	Off	On/Off	U1 U2	
47	Audio Verification Mode	Off	Off	On/Off	U1 U2	
48	Panic Talk - AVM	Off	Off	On/Off	U1 U2	
49	Rechargeable Battery	Off	Off	On/Off	U1 U2	
50	RF Jam Detect	Off	Off	On/Off	U1 U2	