

For the Record

Partner P-16LC

Client Information

Customer: _____

Address: _____

Phone: _____

Installation Date: _____

Contacts

Name: _____

Phone: _____

Name: _____

Phone: _____

Name: _____

Phone: _____

Control: _____

Version: _____

Account: _____

Receiver Number: _____

Installer's Code: _____

Keypad

[F]ire ☐ ON ☐ OFF

Quick-Arm ☐ ON ☐ OFF

[A]uxiliary ☐ ON ☐ OFF

Auto-Arm ☐ ON ☐ OFF

[P]anic ☐ ON ☐ OFF

Auto-Disarm ☐ ON ☐ OFF

Installer Lockout

Installer Lockout ☐ ON ☐ OFF

Zones

Zone	Type	Label	Protected Area
1	_____	_____	_____
2	_____	_____	_____
3	_____	_____	_____
4	_____	_____	_____
5	_____	_____	_____
6	_____	_____	_____
7	_____	_____	_____
8	_____	_____	_____
9	_____	_____	_____
10	_____	_____	_____
11	_____	_____	_____
12	_____	_____	_____
13	_____	_____	_____
14	_____	_____	_____
15	_____	_____	_____
16	_____	_____	_____

Access Codes

Code	Type	Assigned To:	Code	Type	Assigned To:
1			33		
2			34		
3			35		
4			36		
5			37		
6			38		
7			39		
8			40		
9			41		
10			42		
11			43		
12			44		
13			45		
14			46		
15			47		
16			48		
17			49		
18			50		
19			51		
20			52		
21			53		
22			54		
23			55		
24			56		
25			57		
26			58		
27			59		
28			60		
29			61		
30			62		
31			63		
32			64		

NOTES

Mode 20 Programming Worksheets

P-16LC
Version 2.1

[001] First Account Code Page 22

For 3-digit codes, enter [0] as the last digit; [0] will not be transmitted. To program a "0" (zero) in the code, enter hexadecimal A.

[002] First Telephone Number Page 22

[003] First Telephone Number Communication Format Page 22

Default

1 7 _____

[004] Second Account Code Page 22

[005] Second Telephone Number Page 22

[006] Second Telephone Number Communication Format Page 22

Default

1 7 _____

[007] Third Account Code Page 22

[008] Third Telephone Number Page 22

[009] Third Telephone Number Communication Format Page 22

Default

1 7 _____

[010] Fourth Account Code Page 22

[011] Fourth Telephone Number Page 22

[012] Fourth Telephone Number Communication Format Page 22

Default

1 7 _____

[013] Fifth Account Code Page 22

[014] Fifth Telephone Number Page 23

[015] Fifth Telephone Number Communication Format Page 23

Default

1 7 _____

[016] Panel Identification Code Page 23

Default

6 0 6 0

[017] Downloading Telephone Number Page 23

[018] - [022] For Future Use Page 23

[023] RF Account Code Page 23

Default

0 0 0 0

[024] Downlook Account Code Page 23

Default

0 0 0 0

[025] - [030] LINKS1000 Preamble Codes Page 23

Default

[025]	F F F F		Preamble for First Telephone Number
[026]	F F F F		Preamble for Second Telephone Number
[027]	F F F F		Preamble for Third Telephone Number
[028]	F F F F		Preamble for Fourth Telephone Number
[029]	F F F F		Preamble for Fifth Telephone Number
[030]	F F F F		Preamble for Downloading Telephone Number

[031] - [100] For Future Use Page 23

[101] - [116] Zone Definitions Page 24

Address Default

Zone Definitions

[101]	5		Zone 1	0	24-hour Silent
[102]	6		Zone 2	1	24-hour Audible
[103]	6		Zone 3	2	24-hour Pulsed Bell
[104]	6		Zone 4	3	Day Loop (Silent Day/Audible Night)
[105]	6		Zone 5	4	Day Loop and Buzzer
[106]	7		Zone 6	5	Delay 1
[107]	7		Zone 7	6	Delay / Instant
[108]	7		Zone 8	7	Instant
[109]	7		Zone 9	8	Buzzer Only
[110]	7		Zone 10	9	No Alarm
[111]	7		Zone 11	A	Delay 2
[112]	7		Zone 12	B	Probation
[113]	7		Zone 13	C	10-second Buzzer with Report
[114]	7		Zone 14	D	24-Hour Tamper Zone
[115]	7		Zone 15	E	Delay/Instant (Home and Away)
[116]	7		Zone 16		

[117] - [228] For Future Use Page 26

[229] - [269] Trouble Zone Definitions Page 26

Address Default

[229]	<u>C</u>	☐	Auxiliary Zone Alarm
[230]	<u>8</u>	☐	Printer Failure
[231]	<u>C</u>	☐	Fire Trouble•
[232]	<u>C</u>	☐	AC Failure
[233]	<u>C</u>	☐	Auxiliary Power Fuse
[234]	<u>C</u>	☐	Siren Cut
[235]	<u>C</u>	☐	Low Battery
[236]	<u>2</u>	☐	Fire Alarm
[237]	<u>8</u>	☐	Telephone Line Fault
[238]	<u>8</u>	☐	Failure to Communicate Trouble
[239]	<u>C</u>	☐	EEPROM Failure
[240]	<u>C</u>	☐	Fail to Arm Schedule 1
[241]	<u>C</u>	☐	Fail to Arm Schedule 2
[242]	<u>C</u>	☐	Fail to Arm Schedule 3
[243]	<u>C</u>	☐	Keypad Failure

 Reserved

[266]	<u>9</u>	☐	Fire Key Alarm
[267]	<u>9</u>	☐	Panic Key Alarm
[268]	<u>9</u>	☐	Emergency Key Alarm
[269]	<u>1</u>	☐	Invalid Code

Zone Definitions

0	24-hour Silent
1	24-hour Audible
2	24-hour Pulsed Bell
3	Day Loop
4	Day Loop and Buzzer
5	Delay 1
6	Delay / Instant
7	Instant
8	Buzzer Only
9	No Alarm
A	Delay 2
B	Probation
C	10-second Buzzer with Report
D	Tamper Zone
E	Home/Away

• **NOTE: For UL-listed systems, an audible type must be selected for the Fire Trouble**

[270] - [300] For Future Use Page 26

[301] - [316] Event Description and Alarm Codes for Zones 1 to 16 Page 26

Address Default

[301]	<u>3</u> <u>A</u> <u>1</u>	☐	Zone 1
[302]	<u>3</u> <u>A</u> <u>2</u>	☐	Zone 2
[303]	<u>3</u> <u>A</u> <u>3</u>	☐	Zone 3
[304]	<u>3</u> <u>A</u> <u>4</u>	☐	Zone 4
[305]	<u>3</u> <u>A</u> <u>5</u>	☐	Zone 5
[306]	<u>3</u> <u>A</u> <u>6</u>	☐	Zone 6
[307]	<u>3</u> <u>A</u> <u>7</u>	☐	Zone 7
[308]	<u>3</u> <u>A</u> <u>8</u>	☐	Zone 8
[309]	<u>3</u> <u>A</u> <u>9</u>	☐	Zone 9
[310]	<u>3</u> <u>1</u> <u>A</u>	☐	Zone 10
[311]	<u>3</u> <u>1</u> <u>1</u>	☐	Zone 11
[312]	<u>3</u> <u>1</u> <u>2</u>	☐	Zone 12
[313]	<u>3</u> <u>1</u> <u>3</u>	☐	Zone 13
[314]	<u>3</u> <u>1</u> <u>4</u>	☐	Zone 14
[315]	<u>3</u> <u>1</u> <u>5</u>	☐	Zone 15
[316]	<u>3</u> <u>1</u> <u>6</u>	☐	Zone 16

[317] - [428] For Future Use Page 26

[429] - [443] Event Description and Trouble Alarm Reporting Codes Page 26

Address Default

[429]	2,F,2		Auxiliary Zone Alarm
[430]	6,D,B		Printer Failure
[431]	6,F,8		Fire Trouble
[432]	6,F,5		AC Failure
[433]	6,D,4		Auxiliary Power Fuse
[434]	6,F,6		Siren Cut
[435]	6,F,7		Low Battery
[436]	1,F,1		Fire Alarm
[437]	6,D,1		Telephone Line Fault
[438]	6,C,1		Failure to Communicate Trouble
[439]	6,D,5		EEPROM Failure
[440]	6,D,6		Fail to Arm on Schedule 1
[441]	6,D,7		Fail to Arm on Schedule 2
[442]	6,D,8		Fail to Arm on Schedule 3
[443]	6,D,A		Keypad Failure

[444] - [465] For Future Use Page 26

[466] - [471] Keypad Alarm Reporting Codes Page 27

Address Default

[466]	1,6,5		Fire Key Alarm
[467]	2,6,6		Panic Key Alarm
[468]	7,6,7		Emergency Key Alarm
[469]	2,6,9		Invalid Code
[470]			For Future Use
[471]	E,F,F		Cancel Code

[472] - [500] For Future Use Page 27

[501] - [516] Restore Reporting Codes for Zones 1 to 16 Page 27

Address Default

[501]	A,1		Zone 1
[502]	A,2		Zone 2
[503]	A,3		Zone 3
[504]	A,4		Zone 4
[505]	A,5		Zone 5
[506]	A,6		Zone 6
[507]	A,7		Zone 7
[508]	A,8		Zone 8
[509]	A,9		Zone 9
[510]	1,A		Zone 10
[511]	1,1		Zone 11
[512]	1,2		Zone 12
[513]	1,3		Zone 13
[514]	1,4		Zone 14
[515]	1,5		Zone 15
[516]	1,6		Zone 16

NOTE: All Restore Codes use the Event Description programmed at Address 701.

[517] - [628] For Future Use Page 27

[629] - [637] Trouble Restore Reporting Codes Page 27

Address	Default		
[629]	F 2		Auxiliary Zone Alarm Restore
[630]	D B		Printer Failure Restore
[631]	F 8		Fire Trouble Restore
[632]	F 5		AC Failure Restore
[633]	D 4		Auxiliary Power Fuse Restore
[634]	F 6		Siren Cut Restore
[635]	F 7		Low Battery Restore
[636]	F 1		Fire Alarm Restore
[637]	D 1		Telephone Line Fault Restore

[638] - [700] For Future Use Page 27

[701] Event Description for All Restore Codes Page 27

Default

9

[702] - [703] Opening and Closing Event Description and Reporting Codes Page 28

Address	Default	
[702]	4 4 1	User Closing Reporting Code
[703]	5 5 1	User Opening Reporting Code

[704] - [705] Reporting Code for Common Bypass/Unbypass Page 28

Address	Default	
[704]	D D 1	Common Bypass Reporting Code
[705]	E D 2	Common Unbypass Reporting Code

[706] - [715] Event Description and Group Opening and Closing Codes Page 28

Address	Default	Recommended	
[706]	0 0 0	B A 1	Group A Closing Code
[707]	0 0 0	B A 2	Group B Closing Code
[708]	0 0 0	B A 3	Group C Closing Code
[709]	0 0 0	B A 4	Group D Closing Code
[710]	0 0 0	B A A	Common Closing Code
[711]	0 0 0	C A 1	Group A Opening Code
[712]	0 0 0	C A 2	Group B Opening Code
[713]	0 0 0	C A 3	Group C Opening Code
[714]	0 0 0	C A 4	Group D Opening Code
[715]	0 0 0	C A A	Common Opening Code

NOTE: All Closing Codes use the same Event Description

NOTE: All Opening Codes use the same Event Description

[716] - [723] Event Description and User Message Reporting Codes Page 29

Address Default

[716]	8,7,1	_____	User Message 1	NOTE: All User Messages use the same Event Description
[717]	8,7,2	_____	User Message 2	
[718]	8,7,3	_____	User Message 3	
[719]	8,7,4	_____	User Message 4	
[720]	8,7,5	_____	User Message 5	
[721]	8,7,6	_____	User Message 6	
[722]	8,7,7	_____	User Message 7	
[723]	8,7,8	_____	User Message 8	

[724] - [731] Event Description and Installer Message Codes Page 29

Address Default

[724]	8,8,1	_____	Installer Message 1	NOTE: All Installer Messages use the same Event Description
[725]	8,8,2	_____	Installer Message 2	
[726]	8,8,3	_____	Installer Message 3	
[727]	8,8,4	_____	Installer Message 4	
[728]	8,8,5	_____	Installer Message 5	
[729]	8,8,6	_____	Installer Message 6	
[730]	8,8,7	_____	Installer Message 7	
[731]	8,8,8	_____	Installer Message 8	

[732] Event Description and Alarm on Exit Code Page 29

Default

0,0,0 _____

[733] Event Description and Periodic Test Code Page 29

Default

A,7,A _____

[734] Event Description and System Test Lead-in Code Page 29

Default

6,7,9 _____

[735] Event Description and System Test Lead-out Code Page 30

Default

6,7,A _____

[736] Event Description and Download Lead-in Code Page 30

Default

6,0,0 _____

[737] Event Description and Download Lead-out Code Page 30

Default

6,0,0 _____

[738] - [743] For Future Use Page 30

[744] LINKS1000 Event Description and Test Transmission Code Page 30

Default

A,7,1 _____

Mode 21 Programming Worksheets

P-16LC
Version 2.1

[001] Group A Zone Assignment Page 31

Zones programmed as "ON" are assigned to Group A. Refer to Programming Multiple-Option Addresses for information on programming.

Default

<u>ON</u>	☐	Zone 1
<u>ON</u>	☐	Zone 2
<u>ON</u>	☐	Zone 3
<u>ON</u>	☐	Zone 4
<u>ON</u>	☐	Zone 5
<u>ON</u>	☐	Zone 6
<u>ON</u>	☐	Zone 7
<u>ON</u>	☐	Zone 8
<u>ON</u>	☐	Zone 9
<u>ON</u>	☐	Zone 10
<u>ON</u>	☐	Zone 11
<u>ON</u>	☐	Zone 12
<u>ON</u>	☐	Zone 13
<u>ON</u>	☐	Zone 14
<u>ON</u>	☐	Zone 15
<u>ON</u>	☐	Zone 16

[003] Group B Zone Assignment Page 31

Zones programmed as "ON" are assigned to Group B. Refer to Programming Multiple-Option Addresses for information on programming.

Default

<u>OFF</u>	☐	Zone 1
<u>OFF</u>	☐	Zone 2
<u>OFF</u>	☐	Zone 3
<u>OFF</u>	☐	Zone 4
<u>OFF</u>	☐	Zone 5
<u>OFF</u>	☐	Zone 6
<u>OFF</u>	☐	Zone 7
<u>OFF</u>	☐	Zone 8
<u>OFF</u>	☐	Zone 9
<u>OFF</u>	☐	Zone 10
<u>OFF</u>	☐	Zone 11
<u>OFF</u>	☐	Zone 12
<u>OFF</u>	☐	Zone 13
<u>OFF</u>	☐	Zone 14
<u>OFF</u>	☐	Zone 15
<u>OFF</u>	☐	Zone 16

[005] Group C Zone Assignment *Page 31*

Zones programmed as "ON" are assigned to Group C. Refer to Programming Multiple-Option Addresses for information on programming.

Default

☐ OFF	☐	Zone 1
☐ OFF	☐	Zone 2
☐ OFF	☐	Zone 3
☐ OFF	☐	Zone 4
☐ OFF	☐	Zone 5
☐ OFF	☐	Zone 6
☐ OFF	☐	Zone 7
☐ OFF	☐	Zone 8
☐ OFF	☐	Zone 9
☐ OFF	☐	Zone 10
☐ OFF	☐	Zone 11
☐ OFF	☐	Zone 12
☐ OFF	☐	Zone 13
☐ OFF	☐	Zone 14
☐ OFF	☐	Zone 15
☐ OFF	☐	Zone 16

[007] Group D Zone Assignment *Page 31*

Zones programmed as "ON" are assigned to Group D. Refer to Programming Multiple-Option Addresses for information on programming.

Default

☐ OFF	☐	Zone 1
☐ OFF	☐	Zone 2
☐ OFF	☐	Zone 3
☐ OFF	☐	Zone 4
☐ OFF	☐	Zone 5
☐ OFF	☐	Zone 6
☐ OFF	☐	Zone 7
☐ OFF	☐	Zone 8
☐ OFF	☐	Zone 9
☐ OFF	☐	Zone 10
☐ OFF	☐	Zone 11
☐ OFF	☐	Zone 12
☐ OFF	☐	Zone 13
☐ OFF	☐	Zone 14
☐ OFF	☐	Zone 15
☐ OFF	☐	Zone 16

[009] Group A Access Code Assignment Page 31

Access Codes programmed as "ON" are assigned to Group A. Refer to Programming Multiple-Option Addresses for information on programming.

Default			Default		
<u>ON</u>	☐	Access Code 1	<u>ON</u>	☐	Access Code 33
<u>ON</u>	☐	Access Code 2	<u>ON</u>	☐	Access Code 34
<u>ON</u>	☐	Access Code 3	<u>ON</u>	☐	Access Code 35
<u>ON</u>	☐	Access Code 4	<u>ON</u>	☐	Access Code 36
<u>ON</u>	☐	Access Code 5	<u>ON</u>	☐	Access Code 37
<u>ON</u>	☐	Access Code 6	<u>ON</u>	☐	Access Code 38
<u>ON</u>	☐	Access Code 7	<u>ON</u>	☐	Access Code 39
<u>ON</u>	☐	Access Code 8	<u>ON</u>	☐	Access Code 40
<u>ON</u>	☐	Access Code 9	<u>ON</u>	☐	Access Code 41
<u>ON</u>	☐	Access Code 10	<u>ON</u>	☐	Access Code 42
<u>ON</u>	☐	Access Code 11	<u>ON</u>	☐	Access Code 43
<u>ON</u>	☐	Access Code 12	<u>ON</u>	☐	Access Code 44
<u>ON</u>	☐	Access Code 13	<u>ON</u>	☐	Access Code 45
<u>ON</u>	☐	Access Code 14	<u>ON</u>	☐	Access Code 46
<u>ON</u>	☐	Access Code 15	<u>ON</u>	☐	Access Code 47
<u>ON</u>	☐	Access Code 16	<u>ON</u>	☐	Access Code 48
<u>ON</u>	☐	Access Code 17	<u>ON</u>	☐	Access Code 49
<u>ON</u>	☐	Access Code 18	<u>ON</u>	☐	Access Code 50
<u>ON</u>	☐	Access Code 19	<u>ON</u>	☐	Access Code 51
<u>ON</u>	☐	Access Code 20	<u>ON</u>	☐	Access Code 52
<u>ON</u>	☐	Access Code 21	<u>ON</u>	☐	Access Code 53
<u>ON</u>	☐	Access Code 22	<u>ON</u>	☐	Access Code 54
<u>ON</u>	☐	Access Code 23	<u>ON</u>	☐	Access Code 55
<u>ON</u>	☐	Access Code 24	<u>ON</u>	☐	Access Code 56
<u>ON</u>	☐	Access Code 25	<u>ON</u>	☐	Access Code 57
<u>ON</u>	☐	Access Code 26	<u>ON</u>	☐	Access Code 58
<u>ON</u>	☐	Access Code 27	<u>ON</u>	☐	Access Code 59
<u>ON</u>	☐	Access Code 28	<u>ON</u>	☐	Access Code 60
<u>ON</u>	☐	Access Code 29	<u>ON</u>	☐	Access Code 61
<u>ON</u>	☐	Access Code 30	<u>ON</u>	☐	Access Code 62
<u>ON</u>	☐	Access Code 31	<u>ON</u>	☐	Access Code 63
<u>ON</u>	☐	Access Code 32	<u>ON</u>	☐	Access Code 64

Default

<u>ON</u>	☐	Access Code 65 Auto-Arming and Auto-Disarming for Schedule 1
<u>ON</u>	☐	Access Code 66 Auto-Arming and Auto-Disarming for Schedule 2
<u>ON</u>	☐	Access Code 67 Auto-Arming and Auto-Disarming for Schedule 3
<u>ON</u>	☐	Access Code 68 Quick Arming
<u>ON</u>	☐	Access Code 69 System Keyswitch
<u>ON</u>	☐	Access Code 70 Arming by Remote Computer

Access Code 70 will always be used to report arming and disarming through downloading. Access Code 70 does **not** need to be enabled to enable arming and disarming through downloading.

[025] Group B Access Code Assignment Page 31

Access Codes programmed as "ON" are assigned to Group B. Refer to Programming Multiple-Option Addresses for information on programming.

Default			Default		
<u>OFF</u>	☐	Access Code 1	<u>OFF</u>	☐	Access Code 33
<u>OFF</u>	☐	Access Code 2	<u>OFF</u>	☐	Access Code 34
<u>OFF</u>	☐	Access Code 3	<u>OFF</u>	☐	Access Code 35
<u>OFF</u>	☐	Access Code 4	<u>OFF</u>	☐	Access Code 36
<u>OFF</u>	☐	Access Code 5	<u>OFF</u>	☐	Access Code 37
<u>OFF</u>	☐	Access Code 6	<u>OFF</u>	☐	Access Code 38
<u>OFF</u>	☐	Access Code 7	<u>OFF</u>	☐	Access Code 39
<u>OFF</u>	☐	Access Code 8	<u>OFF</u>	☐	Access Code 40
<u>OFF</u>	☐	Access Code 9	<u>OFF</u>	☐	Access Code 41
<u>OFF</u>	☐	Access Code 10	<u>OFF</u>	☐	Access Code 42
<u>OFF</u>	☐	Access Code 11	<u>OFF</u>	☐	Access Code 43
<u>OFF</u>	☐	Access Code 12	<u>OFF</u>	☐	Access Code 44
<u>OFF</u>	☐	Access Code 13	<u>OFF</u>	☐	Access Code 45
<u>OFF</u>	☐	Access Code 14	<u>OFF</u>	☐	Access Code 46
<u>OFF</u>	☐	Access Code 15	<u>OFF</u>	☐	Access Code 47
<u>OFF</u>	☐	Access Code 16	<u>OFF</u>	☐	Access Code 48
<u>OFF</u>	☐	Access Code 17	<u>OFF</u>	☐	Access Code 49
<u>OFF</u>	☐	Access Code 18	<u>OFF</u>	☐	Access Code 50
<u>OFF</u>	☐	Access Code 19	<u>OFF</u>	☐	Access Code 51
<u>OFF</u>	☐	Access Code 20	<u>OFF</u>	☐	Access Code 52
<u>OFF</u>	☐	Access Code 21	<u>OFF</u>	☐	Access Code 53
<u>OFF</u>	☐	Access Code 22	<u>OFF</u>	☐	Access Code 54
<u>OFF</u>	☐	Access Code 23	<u>OFF</u>	☐	Access Code 55
<u>OFF</u>	☐	Access Code 24	<u>OFF</u>	☐	Access Code 56
<u>OFF</u>	☐	Access Code 25	<u>OFF</u>	☐	Access Code 57
<u>OFF</u>	☐	Access Code 26	<u>OFF</u>	☐	Access Code 58
<u>OFF</u>	☐	Access Code 27	<u>OFF</u>	☐	Access Code 59
<u>OFF</u>	☐	Access Code 28	<u>OFF</u>	☐	Access Code 60
<u>OFF</u>	☐	Access Code 29	<u>OFF</u>	☐	Access Code 61
<u>OFF</u>	☐	Access Code 30	<u>OFF</u>	☐	Access Code 62
<u>OFF</u>	☐	Access Code 31	<u>OFF</u>	☐	Access Code 63
<u>OFF</u>	☐	Access Code 32	<u>OFF</u>	☐	Access Code 64

Default

<u>OFF</u>	☐	Access Code 65 Auto-Arming and Auto-Disarming for Schedule 1
<u>OFF</u>	☐	Access Code 66 Auto-Arming and Auto-Disarming for Schedule 2
<u>OFF</u>	☐	Access Code 67 Auto-Arming and Auto-Disarming for Schedule 3
<u>OFF</u>	☐	Access Code 68 Quick Arming
<u>OFF</u>	☐	Access Code 69 System Keyswitch
<u>OFF</u>	☐	Access Code 70 Arming by Remote Computer

[041] Group C Access Code Assignment Page 31

Access Codes programmed as "ON" are assigned to Group C. Refer to Programming Multiple-Option Addresses for information on programming.

Default			Default		
<u>OFF</u>	☐	Access Code 1	<u>OFF</u>	☐	Access Code 33
<u>OFF</u>	☐	Access Code 2	<u>OFF</u>	☐	Access Code 34
<u>OFF</u>	☐	Access Code 3	<u>OFF</u>	☐	Access Code 35
<u>OFF</u>	☐	Access Code 4	<u>OFF</u>	☐	Access Code 36
<u>OFF</u>	☐	Access Code 5	<u>OFF</u>	☐	Access Code 37
<u>OFF</u>	☐	Access Code 6	<u>OFF</u>	☐	Access Code 38
<u>OFF</u>	☐	Access Code 7	<u>OFF</u>	☐	Access Code 39
<u>OFF</u>	☐	Access Code 8	<u>OFF</u>	☐	Access Code 40
<u>OFF</u>	☐	Access Code 9	<u>OFF</u>	☐	Access Code 41
<u>OFF</u>	☐	Access Code 10	<u>OFF</u>	☐	Access Code 42
<u>OFF</u>	☐	Access Code 11	<u>OFF</u>	☐	Access Code 43
<u>OFF</u>	☐	Access Code 12	<u>OFF</u>	☐	Access Code 44
<u>OFF</u>	☐	Access Code 13	<u>OFF</u>	☐	Access Code 45
<u>OFF</u>	☐	Access Code 14	<u>OFF</u>	☐	Access Code 46
<u>OFF</u>	☐	Access Code 15	<u>OFF</u>	☐	Access Code 47
<u>OFF</u>	☐	Access Code 16	<u>OFF</u>	☐	Access Code 48
<u>OFF</u>	☐	Access Code 17	<u>OFF</u>	☐	Access Code 49
<u>OFF</u>	☐	Access Code 18	<u>OFF</u>	☐	Access Code 50
<u>OFF</u>	☐	Access Code 19	<u>OFF</u>	☐	Access Code 51
<u>OFF</u>	☐	Access Code 20	<u>OFF</u>	☐	Access Code 52
<u>OFF</u>	☐	Access Code 21	<u>OFF</u>	☐	Access Code 53
<u>OFF</u>	☐	Access Code 22	<u>OFF</u>	☐	Access Code 54
<u>OFF</u>	☐	Access Code 23	<u>OFF</u>	☐	Access Code 55
<u>OFF</u>	☐	Access Code 24	<u>OFF</u>	☐	Access Code 56
<u>OFF</u>	☐	Access Code 25	<u>OFF</u>	☐	Access Code 57
<u>OFF</u>	☐	Access Code 26	<u>OFF</u>	☐	Access Code 58
<u>OFF</u>	☐	Access Code 27	<u>OFF</u>	☐	Access Code 59
<u>OFF</u>	☐	Access Code 28	<u>OFF</u>	☐	Access Code 60
<u>OFF</u>	☐	Access Code 29	<u>OFF</u>	☐	Access Code 61
<u>OFF</u>	☐	Access Code 30	<u>OFF</u>	☐	Access Code 62
<u>OFF</u>	☐	Access Code 31	<u>OFF</u>	☐	Access Code 63
<u>OFF</u>	☐	Access Code 32	<u>OFF</u>	☐	Access Code 64

Default		
<u>OFF</u>	☐	Access Code 65 Auto-Arming and Auto-Disarming for Schedule 1
<u>OFF</u>	☐	Access Code 66 Auto-Arming and Auto-Disarming for Schedule 2
<u>OFF</u>	☐	Access Code 67 Auto-Arming and Auto-Disarming for Schedule 3
<u>OFF</u>	☐	Access Code 68 Quick Arming
<u>OFF</u>	☐	Access Code 69 System Keyswitch
<u>OFF</u>	☐	Access Code 70 Arming by Remote Computer

[057] Group D Access Code Assignment Page 31

Access Codes programmed as "ON" are assigned to Group D. Refer to Programming Multiple-Option Addresses for information on programming.

Default			Default		
<u>OFF</u>	☐	Access Code 1	<u>OFF</u>	☐	Access Code 33
<u>OFF</u>	☐	Access Code 2	<u>OFF</u>	☐	Access Code 34
<u>OFF</u>	☐	Access Code 3	<u>OFF</u>	☐	Access Code 35
<u>OFF</u>	☐	Access Code 4	<u>OFF</u>	☐	Access Code 36
<u>OFF</u>	☐	Access Code 5	<u>OFF</u>	☐	Access Code 37
<u>OFF</u>	☐	Access Code 6	<u>OFF</u>	☐	Access Code 38
<u>OFF</u>	☐	Access Code 7	<u>OFF</u>	☐	Access Code 39
<u>OFF</u>	☐	Access Code 8	<u>OFF</u>	☐	Access Code 40
<u>OFF</u>	☐	Access Code 9	<u>OFF</u>	☐	Access Code 41
<u>OFF</u>	☐	Access Code 10	<u>OFF</u>	☐	Access Code 42
<u>OFF</u>	☐	Access Code 11	<u>OFF</u>	☐	Access Code 43
<u>OFF</u>	☐	Access Code 12	<u>OFF</u>	☐	Access Code 44
<u>OFF</u>	☐	Access Code 13	<u>OFF</u>	☐	Access Code 45
<u>OFF</u>	☐	Access Code 14	<u>OFF</u>	☐	Access Code 46
<u>OFF</u>	☐	Access Code 15	<u>OFF</u>	☐	Access Code 47
<u>OFF</u>	☐	Access Code 16	<u>OFF</u>	☐	Access Code 48
<u>OFF</u>	☐	Access Code 17	<u>OFF</u>	☐	Access Code 49
<u>OFF</u>	☐	Access Code 18	<u>OFF</u>	☐	Access Code 50
<u>OFF</u>	☐	Access Code 19	<u>OFF</u>	☐	Access Code 51
<u>OFF</u>	☐	Access Code 20	<u>OFF</u>	☐	Access Code 52
<u>OFF</u>	☐	Access Code 21	<u>OFF</u>	☐	Access Code 53
<u>OFF</u>	☐	Access Code 22	<u>OFF</u>	☐	Access Code 54
<u>OFF</u>	☐	Access Code 23	<u>OFF</u>	☐	Access Code 55
<u>OFF</u>	☐	Access Code 24	<u>OFF</u>	☐	Access Code 56
<u>OFF</u>	☐	Access Code 25	<u>OFF</u>	☐	Access Code 57
<u>OFF</u>	☐	Access Code 26	<u>OFF</u>	☐	Access Code 58
<u>OFF</u>	☐	Access Code 27	<u>OFF</u>	☐	Access Code 59
<u>OFF</u>	☐	Access Code 28	<u>OFF</u>	☐	Access Code 60
<u>OFF</u>	☐	Access Code 29	<u>OFF</u>	☐	Access Code 61
<u>OFF</u>	☐	Access Code 30	<u>OFF</u>	☐	Access Code 62
<u>OFF</u>	☐	Access Code 31	<u>OFF</u>	☐	Access Code 63
<u>OFF</u>	☐	Access Code 32	<u>OFF</u>	☐	Access Code 64

Default		
<u>OFF</u>	☐	Access Code 65 Auto-Arming and Auto-Disarming for Schedule 1
<u>OFF</u>	☐	Access Code 66 Auto-Arming and Auto-Disarming for Schedule 2
<u>OFF</u>	☐	Access Code 67 Auto-Arming and Auto-Disarming for Schedule 3
<u>OFF</u>	☐	Access Code 68 Quick Arming
<u>OFF</u>	☐	Access Code 69 System Keyswitch
<u>OFF</u>	☐	Access Code 70 Arming by Remote Computer

[072] Group Opening / Closing Report Selection Page 31

Default

- | | | | |
|---|------------------------------|--------------------------|---|
| 1 | ☐ ON | ☐ | Group A Opening / Closing Report enable |
| 2 | ☐ ON | ☐ | Group B Opening / Closing Report enable |
| 3 | ☐ ON | ☐ | Group C Opening / Closing Report enable |
| 4 | ☐ ON | ☐ | Group D Opening / Closing Report enable |
| 5 | ☐ OFF | ☐ | Not Used |
| 6 | ☐ OFF | ☐ | Not Used |
| 7 | ☐ OFF | ☐ | Not Used |

[073] Group A Telephone Number Selection Page 31

Default

- | | | | |
|---|------------------------------|--------------------------|--|
| 1 | ☐ ON | ☐ | Phone Number 1 |
| 2 | ☐ OFF | ☐ | Phone Number 2 |
| 3 | ☐ OFF | ☐ | Phone Number 3 |
| 4 | ☐ OFF | ☐ | Phone Number 4 |
| 5 | ☐ OFF | ☐ | Phone Number 5 |
| 6 | ☐ OFF | ☐ | Printer |
| 7 | ☐ OFF | ☐ | LINKS2000 <i>Must be OFF for UL-listed systems</i> |

[074] Group B Telephone Number Selection Page 31

Default

- | | | | |
|---|------------------------------|--------------------------|--|
| 1 | ☐ ON | ☐ | Phone Number 1 |
| 2 | ☐ OFF | ☐ | Phone Number 2 |
| 3 | ☐ OFF | ☐ | Phone Number 3 |
| 4 | ☐ OFF | ☐ | Phone Number 4 |
| 5 | ☐ OFF | ☐ | Phone Number 5 |
| 6 | ☐ OFF | ☐ | Printer |
| 7 | ☐ OFF | ☐ | LINKS2000 <i>Must be OFF for UL-listed systems</i> |

[075] Group C Telephone Number Selection Page 31

Default

- | | | | |
|---|------------------------------|--------------------------|--|
| 1 | ☐ ON | ☐ | Phone Number 1 |
| 2 | ☐ OFF | ☐ | Phone Number 2 |
| 3 | ☐ OFF | ☐ | Phone Number 3 |
| 4 | ☐ OFF | ☐ | Phone Number 4 |
| 5 | ☐ OFF | ☐ | Phone Number 5 |
| 6 | ☐ OFF | ☐ | Printer |
| 7 | ☐ OFF | ☐ | LINKS2000 <i>Must be OFF for UL-listed systems</i> |

[076] Group D Telephone Number Selection Page 31

Default

- | | | | |
|---|------------------------------|--------------------------|--|
| 1 | ☐ ON | ☐ | Phone Number 1 |
| 2 | ☐ OFF | ☐ | Phone Number 2 |
| 3 | ☐ OFF | ☐ | Phone Number 3 |
| 4 | ☐ OFF | ☐ | Phone Number 4 |
| 5 | ☐ OFF | ☐ | Phone Number 5 |
| 6 | ☐ OFF | ☐ | Printer |
| 7 | ☐ OFF | ☐ | LINKS2000 <i>Must be OFF for UL-listed systems</i> |

[077] Trouble Events Telephone Number Selection Page 32

Default

- | | | | |
|---|------------|--------------------------|--|
| 1 | <u>ON</u> | ☐ | Phone Number 1 |
| 2 | <u>OFF</u> | ☐ | Phone Number 2 |
| 3 | <u>OFF</u> | ☐ | Phone Number 3 |
| 4 | <u>OFF</u> | ☐ | Phone Number 4 |
| 5 | <u>OFF</u> | ☐ | Phone Number 5 |
| 6 | <u>OFF</u> | ☐ | Printer |
| 7 | <u>OFF</u> | ☐ | LINKS2000 <i>Must be OFF for UL-listed systems</i> |

[078] User / Installer Messages Telephone Number Selection Page 32

Default

- | | | | |
|---|------------|--------------------------|--|
| 1 | <u>ON</u> | ☐ | Phone Number 1 |
| 2 | <u>OFF</u> | ☐ | Phone Number 2 |
| 3 | <u>OFF</u> | ☐ | Phone Number 3 |
| 4 | <u>OFF</u> | ☐ | Phone Number 4 |
| 5 | <u>OFF</u> | ☐ | Phone Number 5 |
| 6 | <u>OFF</u> | ☐ | Printer |
| 7 | <u>OFF</u> | ☐ | LINKS2000 <i>Must be OFF for UL-listed systems</i> |

[079] Open / Close Reporting Telephone Number Selection Page 32

Default

- | | | | |
|---|------------|--------------------------|--|
| 1 | <u>OFF</u> | ☐ | Phone Number 1 |
| 2 | <u>OFF</u> | ☐ | Phone Number 2 |
| 3 | <u>OFF</u> | ☐ | Phone Number 3 |
| 4 | <u>OFF</u> | ☐ | Phone Number 4 |
| 5 | <u>OFF</u> | ☐ | Phone Number 5 |
| 6 | <u>OFF</u> | ☐ | Printer |
| 7 | <u>OFF</u> | ☐ | LINKS2000 <i>Must be OFF for UL-listed systems</i> |

[080] Bypass Inhibit Page 32

Zones programmed as "OFF" may be bypassed using the Mode 01 Keypad Command; zones programmed as "ON" may not be bypassed. Refer to Programming Multiple-Option Address for information on programming.

Default

- | | | |
|------------|--------------------------|--------|
| <u>OFF</u> | ☐ | Zone 1 |
| <u>OFF</u> | ☐ | Zone 2 |
| <u>OFF</u> | ☐ | Zone 3 |
| <u>OFF</u> | ☐ | Zone 4 |
| <u>OFF</u> | ☐ | Zone 5 |
| <u>OFF</u> | ☐ | Zone 6 |
| <u>OFF</u> | ☐ | Zone 7 |
| <u>OFF</u> | ☐ | Zone 8 |

Default

- | | | |
|------------|--------------------------|---------|
| <u>OFF</u> | ☐ | Zone 9 |
| <u>OFF</u> | ☐ | Zone 10 |
| <u>OFF</u> | ☐ | Zone 11 |
| <u>OFF</u> | ☐ | Zone 12 |
| <u>OFF</u> | ☐ | Zone 13 |
| <u>OFF</u> | ☐ | Zone 14 |
| <u>OFF</u> | ☐ | Zone 15 |
| <u>OFF</u> | ☐ | Zone 16 |

[081] For Future Use *Page 32*
[082] Zone Transmission Delay Select *Page 32*

Zones programmed as "ON" are will have a delay time as programmed in Mode 22 Address [027]. Refer to Programming Multiple-Option Addresses for information on programming.

Default

<u>OFF</u>	☐	Zone 1
<u>OFF</u>	☐	Zone 2
<u>OFF</u>	☐	Zone 3
<u>OFF</u>	☐	Zone 4
<u>OFF</u>	☐	Zone 5
<u>OFF</u>	☐	Zone 6
<u>OFF</u>	☐	Zone 7
<u>OFF</u>	☐	Zone 8

Default

<u>OFF</u>	☐	Zone 9
<u>OFF</u>	☐	Zone 10
<u>OFF</u>	☐	Zone 11
<u>OFF</u>	☐	Zone 12
<u>OFF</u>	☐	Zone 13
<u>OFF</u>	☐	Zone 14
<u>OFF</u>	☐	Zone 15
<u>OFF</u>	☐	Zone 16

Mode 22 Programming Worksheets

P-16LC
Version 2.1

[001] - [008] System Options Page 33

Address	Default			
 1	<u>OFF</u> ☐	Option 1	Open / Close Report Select	
2	<u>OFF</u> ☐	Option 2	Close Confirmation Option	
3	<u>OFF</u> ☐	Option 3	Force Arming Select	
4	<u>ON</u> ☐	Option 4	Communicator Enable/Disable	
5	<u>OFF</u> ☐	Option 5	Quick-Arm Select	
6	<u>ON</u> ☐	Option 6	Alarm Memory Indication	
7	<u>ON</u> ☐	Option 7	Siren Driver Enabled	
8	<u>OFF</u> ☐	Option 8	Bell Squawk Enabled	

Address	Default			
[002] 1	<u>ON</u> ☐	Option 9	Access Code Required for Bypassing	
2	<u>OFF</u> ☐	Option 10	<i>Reserved</i>	
3	<u>OFF</u> ☐	Option 11	Bypass Report on Exit	
4	<u>OFF</u> ☐	Option 12	Common Bypass Report	
5	<u>ON</u> ☐	Option 13	Bypassed Zones Display on Exit	
6	<u>OFF</u> ☐	Option 14	Quick Exit	
7	<u>OFF</u> ☐	Option 15	No arming on AC failure and low battery	
8	<u>OFF</u> ☐	Option 16	<i>Reserved</i>	

Address	Default			
[003] 1	<u>OFF</u> ☐	Option 17	Master Code not Changeable	
2	<u>ON</u> ☐	Option 18	Only Master Code able to send User Message	
3	<u>OFF</u> ☐	Option 19	Immediate Restore	
4	<u>OFF</u> ☐	Option 20	Memory Security Switch	
5	<u>OFF</u> ☐	Option 21	Keyswitch Arming/Disarming	
6	<u>OFF</u> ☐	Option 22	Maintained Keyswitch Arming/Disarming	
7	<u>OFF</u> ☐	Option 23	<i>Reserved</i>	
8	<u>OFF</u> ☐	Option 24	<i>Reserved</i>	

Address	Default			
[004] 1	<u>ON</u> ☐	Option 25	Programmable Output 2 Normally High	
2	<u>OFF</u> ☐	Option 26	Installer Lockout	
3	<u>OFF</u> ☐	Option 27	Keypad Lockout	
4	<u>OFF</u> ☐	Option 28	AC in at 50Hz (European installation)	
5	<u>ON</u> ☐	Option 29	Auto-Answer for Downloading	
6	<u>OFF</u> ☐	Option 30	User-Initiated Downloading	
	<u>OFF</u> ☐			
	<u>OFF</u> ☐			

Address	Default			
[005]	1	<u>ON</u> ☐	Option 33	DTMF/Pulse Dialing Select
	2	<u>OFF</u> ☐	Option 34	1400Hz / 2300Hz Radionics Select
	3	<u>OFF</u> ☐	Option 35	Forced Dialing Option
	4	<u>OFF</u> ☐	Option 36	Dialer Presence Tone
	5	<u>OFF</u> ☐	Option 37	<i>Reserved</i>
	6	<u>OFF</u> ☐	Option 38	User Programs Group Selection
	7	<u>OFF</u> ☐	Option 39	Test Transmission Only When Armed
	8	<u>OFF</u> ☐	Option 40	Forced Arming on Delay/Instant Zones

Address	Default			
[006]	1	<u>OFF</u> ☐	Option 41	<i>Reserved</i>
	2	<u>OFF</u> ☐	Option 42	<i>Reserved</i>
	3	<u>OFF</u> ☐	Option 43	<i>Reserved</i>
	4	<u>OFF</u> ☐	Option 44	<i>Reserved</i>
	5	<u>OFF</u> ☐	Option 45	<i>Reserved</i>
	6	<u>OFF</u> ☐	Option 46	<i>Reserved</i>
	7	<u>OFF</u> ☐	Option 47	Audio Enable
	8	<u>OFF</u> ☐	Option 48	Downlook Enable Must be OFF for UL-listed systems

Address	Default			
[007]	1	<u>OFF</u> ☐	Option 49	<i>Reserved</i>
	2	<u>OFF</u> ☐	Option 50	<i>Reserved</i>
	3	<u>OFF</u> ☐	Option 51	Common Close/Open Report
	4	<u>OFF</u> ☐	Option 52	<i>Reserved</i>
	5	<u>OFF</u> ☐	Option 53	<i>Reserved</i>
	6	<u>OFF</u> ☐	Option 54	Auto-Arm Bell Squawk
	7	<u>OFF</u> ☐	Option 55	<i>Reserved</i>
	8	<u>OFF</u> ☐	Option 56	<i>Reserved</i>

Address	Default			
[008]	1	<u>OFF</u> ☐	Option 57	<i>Reserved</i>
	2	<u>OFF</u> ☐	Option 58	<i>Reserved</i>
	3	<u>OFF</u> ☐	Option 59	LINKS1000/2000 Select
	4	<u>OFF</u> ☐	Option 60	<i>Reserved</i>
	5	<u>OFF</u> ☐	Option 61	<i>Reserved</i>
	6	<u>OFF</u> ☐	Option 62	<i>Reserved</i>
	7	<u>OFF</u> ☐	Option 63	<i>Reserved</i>
	8	<u>OFF</u> ☐	Option 64	<i>Reserved</i>

[009] - [020] For Future Use *Page 36*

[021] - [023] Entrance and Exit Delays Page 36

Address Default

[021]	0,3,0		Entrance Delay 1 (seconds)
[022]	0,4,5		Entrance Delay 2 (seconds)
[023]	0,6,0		Exit Delay (seconds)

[024] - [031] System Times Page 36

Address Default

[024]	0,0,6		Siren / Bell Duration (minutes)
[025]	0,0,0		Fire Zone Activation Delay (seconds) Must be set as '000' for UL installations
[026]	0,3,0		Fire Zone Restore Delay (seconds)
[027]	0,1,5		Zone Alarm Delay (seconds)
[028]	0,2,5		Fire Zone Transmission Delay (seconds)
[029]	1,8,0		Auto-Arm Delay (seconds)
[030]	2,4		Test Transmission Period (hours) Must be set as '24' for UL installations
[031]	9,9,9,9		Test Transmission Start Time

[032] For Future Use Page 37

[033] Printer Set-up Page 37

Default

0,4		Default: 2400 baud
-----	--	--------------------

[034] For Future Use Page 37

[035] - [038] Programmable Output Types Page 37

Address Default

[035]	9,9		Programmable Output 1
[036]	1,3		Programmable Output 2
[037]	9,9		Programmable Output 3
[038]	9,9		Programmable Output 4

Output Types

01	Kiss-Off Signal	20	Follow Chime
02	Fail to Communicate	21	Follow Buzzer
03	Courtesy Light	22	Serial Printer Output (PGM1 only)
04	Follow Bell/Siren	23	Ground Start
05	Follow Group A Arm/Disarm Status	24	Strobe Output
06	Follow Group B Arm/Disarm Status	25	30-minute Strobe Output
07	Follow Group C Arm/Disarm Status	26	Bell/Siren Output for Group A
08	Follow Group D Arm/Disarm Status	27	Bell/Siren Output for Group B
09	Follow Group A Ready Status	28	Bell/Siren Output for Group C
10	Follow Group B Ready Status	29	Bell/Siren Output for Group D
11	Follow Group C Ready Status	30	Follow Auto-Arm Buzzer
12	Follow Group D Ready Status	31	Follow Away Status
13	Utility Output (No Code)	32	Follow Trouble
14	Utility Output (Any valid Code)	33	Follow Low Battery
15	Utility Output (Keys [4] & [5])	34	Follow Fire Alarm
16	Utility Output (Group A Code)	35	Follow AC Failure
17	Utility Output (Group B Code)	36	Follow Telephone Line Monitor
18	Utility Output (Group C Code)	37	RF Control (PGM3 only) Not for use with UL systems
19	Utility Output (Group D Code)	38	Audio Control

[039] - [062] For Future Use Page 37

[063] Language Selection for Printer Page 37

Default

01

01 1st Language (English)

02 2nd Language (Spanish)

[064] For Future Use Page 35

[065] Maximum Alarms Reports Per Zone Per Armed Period Page 37

Default

0F

Must be programmed as 0F for UL installations

[066] Forced Answer Zone Page 37

Default

00

Must be programmed as 00 for UL installations

Mode 23 Programming Worksheets

P-16LC
Version 2.1

[001] **Installer Access Code** Page 38

Default

1 6 0 0 _ _ _ _

[002] **Downloading Access Code** Page 38

Default

1 6 1 6 _ _ _ _

[003] **For Future Use** Page 38

[004]-[026] **Special Application Data** Page 38

Address Default

[004]	1 0	_ _	Total number of DTMF dialing attempts to reach telephone number
[005]	1 2	_ _	Number of rings before control panel will answer telephone line (program as [99] for Double-Ring operation)
[006]	0 2	_ _	Delay time used for "C" in telephone number
[007]	1 0	_ _	Pager wait time for kissoff (seconds)
[008]	1 0	_ _	Tape Dialer delay before data transmission (seconds)
[009]	0 2	_ _	Tape Dialer signature (number of tones)
[010]	0 2	_ _	Tape Dialer kissoff (number of tones)
[011]	1 1	_ _	DTMF "on" time (× 10 ms)
[012]	0 7	_ _	DTMF "off" time (× 10 ms)
[013]	7 5	_ _	High Dial Tone Frequency (× 10Hz)
[014]	2 5	_ _	Low Dial Tone Frequency (× 10 Hz)
[015]	3 0	_ _	Wait time for Handshake (seconds)
[016]	3 0	_ _	Wait time for Kissoff (× 100 ms)
[017]	2 0	_ _	Hold Off time (seconds)
[018]	2 5	_ _	Off Line Time (seconds)
[019]	3 0	_ _	Delay between Handshake and Data (× 10 ms)
[020]	3 0	_ _	Inter-round delay for 10 to 40 baud (× 100 ms)
[021]	1 6	_ _	Inter-round delay for DTMF data (× 50 ms)
[022]	6 0	_ _	Pulse Dial Break Time (ms)
[023]	4 5	_ _	Answering Machine Double Call Timer (seconds)
[024]	1 B 3 4	_ _ _ _	Emphasised Printer Data
[025]	1 B 3 5	_ _ _ _	De-emphasised Printer Data
[026]	0 8	_ _	Pager 3 Delay Before Data Transmission (seconds)

[027] - [050] **For Future Use** Page 39

[051] - [066] Zone Configuration for Zones 1 through 16 Page 40

Address Default

[051]	<u>0</u>	☐	Zone 1	<i>Program...</i>	<i>...for Zone Configuration</i>
[052]	<u>0</u>	☐	Zone 2	0	End-of-Line Resistor Zone
[053]	<u>0</u>	☐	Zone 3	1	Normally Closed Zone •
[054]	<u>0</u>	☐	Zone 4	2	Normally Open Zone •
[055]	<u>0</u>	☐	Zone 5		• Not for use with UL listed systems
[056]	<u>0</u>	☐	Zone 6		
[057]	<u>0</u>	☐	Zone 7		
[058]	<u>0</u>	☐	Zone 8		
[059]	<u>0</u>	☐	Zone 9		
[060]	<u>0</u>	☐	Zone 10		
[061]	<u>0</u>	☐	Zone 11		
[062]	<u>0</u>	☐	Zone 12		
[063]	<u>0</u>	☐	Zone 13		
[064]	<u>0</u>	☐	Zone 14		
[065]	<u>0</u>	☐	Zone 15		
[066]	<u>0</u>	☐	Zone 16		

[067] - [200] For Future Use Page 40

[201] - [216] Downlook Camera Selection for Zones 1 through 16 Page 40

Address Default

[201]	<u>0</u>	☐	Zone 1
[202]	<u>0</u>	☐	Zone 2
[203]	<u>0</u>	☐	Zone 3
[204]	<u>0</u>	☐	Zone 4
[205]	<u>0</u>	☐	Zone 5
[206]	<u>0</u>	☐	Zone 6
[207]	<u>0</u>	☐	Zone 7
[208]	<u>0</u>	☐	Zone 8
[209]	<u>0</u>	☐	Zone 9
[210]	<u>0</u>	☐	Zone 10
[211]	<u>0</u>	☐	Zone 11
[212]	<u>0</u>	☐	Zone 12
[213]	<u>0</u>	☐	Zone 13
[214]	<u>0</u>	☐	Zone 14
[215]	<u>0</u>	☐	Zone 15
[216]	<u>0</u>	☐	Zone 16

[217] - [328] For Future Use Page 40

[329] Downlook Camera Selection for Keypad Zones Page 40

Default

0

[330] Downlook Camera Selection for Keypad Arming / Disarming Page 40

Default

0

[331] - [340] For Future Use Page 40

[341] Downlook Control Code Page 40

Default

0

[342] Downlook Picture Count: Zones Page 40

Default

3

[343] Downlook Picture Count: Keypad and Arming and Disarming Page 40

Default

2

[344] Delay Between Zone Activation and Picture Capture (×100ms) Page 40

Default

3 0

[345] Downlook Telephone Number Selection Page 40

Default

1

Notes

Notes

P R O G R A M M I N G

W O R K S H E E T S

P-16LC SECURITY SYSTEM

Partners

BY

541-5177

Table of Contents

FOR THE RECORD	1
MODE 20 PROGRAMMING WORKSHEETS	3
[001] First Account Code	3
[002] First Telephone Number	3
[003] First Telephone Number Communication Format	3
[004] Second Account Code	3
[005] Second Telephone Number	3
[006] Second Telephone Number Communication Format	3
[007] Third Account Code	3
[008] Third Telephone Number	3
[009] Third Telephone Number Communication Format	3
[010] Fourth Account Code	3
[011] Fourth Telephone Number	3
[012] Fourth Telephone Number Communication Format	3
[013] Fifth Account Code	3
[014] Fifth Telephone Number	3
[015] Fifth Telephone Number Communication Format	3
[016] Panel Identification Code	4
[017] Downloading Telephone Number	4
[018] - [022] For Future Use	4
[023] RF Account Code	4
[024] Downlook Account Code	4
[025] - [030] LINKS Preamble Codes	4
[031] - [100] For Future Use	4
[101] - [116] Zone Definitions	4
[117] - [228] For Future Use	5
[229] - [269] Trouble Zone Definitions	5
[270] - [300] For Future Use	5
[301] - [316] Event Description and Alarm Codes for Zones 1 to 16	5
[317] - [428] For Future Use	6
[429] - [442] Event Description and Trouble Alarm Reporting Codes	6
[444] - [465] For Future Use	6
[466] - [471] Keypad Alarm Reporting Codes	6
[472] - [500] For Future Use	6
[501] - [516] Restore Reporting Codes for Zones 1 - 16	6
[517] - [628] For Future Use	7
[629] - [637] Trouble Restore Reporting Codes	7
[638] - [700] For Future Use	7
[701] Event Description for All Restore Codes	7
[702] - [703] Opening and Closing Event Description and Reporting Codes	7
[704] - [705] Reporting Code for Common Bypass/Unbypass	7
[706] - [715] Event Description and Group Opening and Closing Codes	7
[716] - [723] Event Description and User Message Reporting Codes	8
[724] - [731] Event Description and Installer Message Codes	8
[732] Event Description and Alarm on Exit Code	8
[733] Event Description and Periodic Test Code	8
[734] System Test Lead-in Code	8
[735] System Test Lead-out Code	8
[736] Event Description and Downloading Lead-in Code	8
[737] Event Description and Downloading Lead-out Code	8
[738] - [743] For Future Use	8
[744] LINKS1000 Event Description and Test Transmission Code	8

MODE 21 PROGRAMMING WORKSHEETS**9**

[001] Group A Zone Assignment	9
[003] Group B Zone Assignment	9
[005] Group C Zone Assignment	10
[007] Group D Zone Assignment	10
[009] Group A Access Code Assignment	11
[025] Group B Access Code Assignment	12
[041] Group C Access Code Assignment	13
[057] Group D Access Code Assignment	14
[073] Group A Telephone Number Selection	15
[074] Group B Telephone Number Selection	15
[075] Group C Telephone Number Selection	15
[076] Group D Telephone Number Selection	15
[077] Trouble Events Telephone Number Selection	16
[078] User / Installer Messages Telephone Number Selection	16
[079] Open / Close Reporting Telephone Number Selection	16
[080] Bypass Inhibit	16
[082] Zone Transmission Delay Section	17

MODE 22 PROGRAMMING WORKSHEETS**18**

[001] - [006] System Options	18
[009] - [020] For Future Use	19
[021] - [023] Entrance and Exit Delays	20
[024] - [031] System Times	20
[032] For Future Use	20
[033] Printer Setup	20
[034] For Future Use	20
[035] - [037] Programmable Output Types	20
[038] - [062] For Future Use	21
[063] Language Selection for Printer	21
[064] For Future Use	21
[065] Maximum Alarms Per Zone Per Armed Period	21
[066] Forced Answer Zone	21

MODE 23 PROGRAMMING WORKSHEETS**22**

[001] Installer Access Code	22
[002] Downloading Access Code	22
[003] For Future Use	22
[004]-[026] Special Application Data	22
[027] - [050] For Future Use	22
[051] - [066] Zone Configuration for Zones 1 through 16	23
[067] - [200] For Future Use	23
[201] - [216] Downlook Camera Selection for Zones 1 through 16	23
[217] - [328] For Future Use	23
[329] Downlook Camera Selection for Keypad	24
[330] Downlook Camera Selection for Arm/Disarm	24
[331] - [340] For Future Use	24
[341] Downlook Control Code	24
[342] Downlook Picture Count: Zones	24
[343] Downlook Picture Count: Keypad and Arming and Disarming	24
[344] Delay Between Zone Activation and Picture Capture (×100ms)	24
[345] Downlook Telephone Number Selection	24
