

PROGRAMMING INFORMATION

For Series XR10 COMMAND PROCESSOR Panels

Name _____ Account Number _____ Phone _____ Date _____
 Address _____ City _____ State _____ Zip _____

COMMUNICATION

Communication Type NONE DD 4 - 2
 Account Number _ _ _ _ (1 to 65,535)
 Transmission Delay _ _ (0 to 60 in 10 sec. increments)
 DTMF NO YES
 Test Frequency _ _ (0 to 60 days)

Receiver 1

Alarm NO YES
 Supv/Trouble NO YES
 O/C & User NO YES
 Test Report NO YES
 Backup NO YES

First Phone Number _ _ _ _ _
 Second Phone Number _ _ _ _ _

Receiver 2

Pager NO YES
 Alarm NO YES
 Supv/Trouble NO YES
 O/C & User NO YES
 Test Report NO YES
 Backup NO YES

First Phone Number _ _ _ _ _
 Second Phone Number _ _ _ _ _
 Pager ID Number _ _ _ _ _

REMOTE OPTIONS

Remote Key _ _ _ _ _
 Manufacturer Authorization NO YES
 Armed Rings _ _ (0 to 15)
 Disarmed Rings _ _ (0 to 15)
 Alarm Receiver NO YES
 Service Receiver NO YES
 Disarm NO YES

SYSTEM REPORTS

Opening/Closing Reports NO YES
 Abort Reports NO YES
 Zone Restoral Reports NO YES DISARM
 Bypass Reports NO YES
 Code Change Reports NO YES
 Ambush NO YES

SYSTEM OPTIONS

All/Perimeter NO YES
 Closing Code NO YES
 Entry Delay 1 _ _ _ (0 to 250 secs.)
 Entry Delay 2 _ _ _ (0 to 250 secs.)
 Exit Delay _ _ _ (0 to 250 secs.)
 Cross Zone Time _ _ _ (0 to 250 secs.)
 Power Fail Delay _ _ _ (0 to 9 hrs.)
 Reset Swinger Bypass NO YES

OUTPUT OPTIONS

Bell Cutoff Time _ _ (0 to 15 mins.)
 Automatic Bell Test NO YES
 Bell Action
 Fire Zones Steady Pulse Temp None
 Burglary Zones Steady Pulse Temp None
 Supervisory Zones Steady Pulse Temp None
 Panic Zones Steady Pulse Temp None
 Emergency Zones Steady Pulse Temp None
 Auxiliary 1 Zones Steady Pulse Temp None
 Auxiliary 2 Zones Steady Pulse Temp None
 Output Action . . .
 Cutoff Outputs 1 2 3 4
 Cutoff Time _ _ (0 to 15 mins.)
 Communication Fail Output _ (0 to 4)
 Fire Alarm Output _ (0 to 4)
 Fire Trouble Output _ (0 to 4)
 Ambush Output _ (0 to 4)
 Entry Output _ (0 to 4)
 Exit Output _ (0 to 4)
 Ready Output _ (0 to 4)
 Armed Output _ (0 to 4)
 Burglary Output _ (0 to 4)
 Ground Start Output _ (0 to 4)

Automatic Recall Test report time: ____ : ____ AM PM

XR10 Programming Information

ZONE INFORMATION	Type	Area	Disarmed Open			Disarmed Short			Armed Open			Armed Short						
	-- NT																	
	Assign Area & Disarmed condition for NT, DY, EX, A1, A2, AR only	DY EX																
	Assign an Entry Delay for EX (exit) type loop only	FI PN																
	Zone Type Defaults	Abbr.																
			Message	Output	Action	Message	Output	Action	Message	Output	Action	Message	Output	Action	Swinger	Entry Delay	Cross Zone	Priority
			A	0	S	A	0	S	A	0	S	A	0	S	N	1	N	N
			T	to	P	T	to	P	T	to	P	T	to	P	or	or	or	or
			L	4	M	L	4	M	L	4	M	L	4	M	Y	2	Y	Y
			-		F	-		F	-		F	-		F				
NIGHT	NT	PERIM	-	0	-	-	0	-	A	0	-	A	0	-	Y		N	N
DAY	DY	PERIM	T	0	-	T	0	-	A	0	-	A	0	-	Y		N	N
EXIT	EX	PERIM	-	0	-	-	0	-	A	0	-	A	0	-	Y	1	N	N
FIRE	FI								T	0	-	A	0	-	N		N	N
PANIC	PN								T	0	-	A	0	-	N		N	N
EMERGENCY	EM								T	0	-	A	0	-	N		N	N
SUPERVISORY	SV								T	0	-	A	0	-	N		N	N
AUXILIARY 1	A1	PERIM	T	0	-	A	0	-	T	0	-	A	0	-	N		N	N
AUXILIARY 2	A2	PERIM	T	0	-	A	0	-	T	0	-	A	0	-	N		N	N
FIRE VERIFY	FV								T	0	-	A	0	-	N			N
ARMING	AR	ALL																
No.	Name																	
1	_____	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
2	_____	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
3	_____	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
4	_____	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
5	_____	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
6	_____	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
7	_____	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
8	_____	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
9	_____	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
10	_____	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---

■ = These zone functions are not available for this zone type.

- = This function is not enabled for this zone type.