

# Ademco via16 PROGRAMMING FORM

THIS PROGRAMMING FORM INCORPORATES SYSTEM ENHANCEMENTS INVOLVING FIELDS \*28, \*35, \*36, \*49, \*50, \*57, \*76-\*91 AND MAY ONLY BE USED TO PROGRAM CONTROLS WITH THOSE ENHANCEMENTS.

FIELD FUNCTION PROGRAMMED VALUES [ ] = Default Value

## SYSTEM ARMING (\*20-\*28)

- \*20 MASTER SECURITY CODE     Enter 4 digits, 0-9 [4][1][1][0]
- \*21 QUICK ARM ENABLE †  [0 = no], 1 = yes
- \*23 FORCED BYPASS FUNCTION †  [0 = no], 1 = yes
- \*24 RF RECEIVER HOUSE ID CODE   With 4281, enter 0-31 House ID. Otherwise enter [00].
- \*28 CONFIRMATION OF ARMING DING †  [0 = no], 1 = yes

## ZONE RESPONSE PROGRAMMING (\*29-\*38)

- \*29 FIRE SOUNDER TIMEOUT DISABLE †  [0 = no], 1 = yes
- \*30 ALARM BELL TIMEOUT †  0 = none; [1 = 4 min]; 2 = 8 min; 3 = 12 min

### ZONE TYPES FOR PROGRAMMING FIELDS \*35-37

0 = Zone Disabled (or Undefined)  
 1 = ENTRY/EXIT, Burglary  
 2 = not used  
 3 = PERIMETER, Burglary  
 4 = INTERIOR/FOLLOWER, Burglary  
 5 = TROUBLE BY DAY/ALARM BY NIGHT, Burglary  
 6 = 24 Hr (Silent)  
 7 = 24 Hr (Audible)  
 8 = 24 Hr (Auxiliary)  
 9 = FIRE (Fields \*35 and \*37 only)  
 10 = INTERIOR w/DELAY, Burglary (To program, enter # + 10)

- \*35 ZONE 5 RESPONSE TYPE  [9]
- \*36 ZONE 6 RESPONSE TYPE  [3]
- \*37 ZONE 7 RESPONSE TYPE  Console Key B or \*8# Panic. Only zone types 0, [8], 7, 8, 9 applicable.
- \*38 ENTRY DELAY †  0 = 0 sec; 1 = 20 sec; 2 = 30 sec; 3 = 45 sec  
 EXIT Delay = ENTRY Delay + 15 sec

## DIALER PROGRAMMING (\*40-\*49)

- \*40 PABX ACCESS CODE     Enter 4 digits, 0-9. If fewer than 4 digits entered, exit by pressing \* (and press 41, if entering next field). To clear entries from field, press \*40\*.
- \*41 PRIMARY PHONE No.             Enter up to 12 digits, 0-9. Do not fill unused spaces. If fewer than 12 digits entered, exit by pressing \* (and press 42, if entering next field). To clear entries from field, press \*41\*.
- \*42 SECONDARY PHONE No.             Enter up to 12 digits, 0-9. Do not fill unused spaces. If fewer than 12 digits entered, exit by pressing \* (and press 43, if entering next field). To clear entries from field, press \*42\*.
- \*43 SUBSCRIBER ACCOUNT No.     Enter 0-9; #+11 for B; #+12 for C; #+13 for D; #+14 for E; #+15 for F. Enter \* as 4th digit, if 3+1 dialer reporting is to be used. If only 3 digits used, exit by pressing \* (and press 44, if entering next field). To clear entries from field, press \*43\*.

Examples: For Acct No. 1234, enter:

1  2  3  4

For Acct No. B234, enter:

#+11  2  3  4

For Acct No. 123, enter:

1  2  3  \*

- \*44 REPORT FORMAT ☐ [0 = 3+1, 4+1 ADEMCO L/S STANDARD] 6 or undefined = 4+2 ADEMCO EXPRESS  
 1 = 3+1, 4+1 RADIONICS STANDARD 7 = ADEMCO CONTACT ID REPORTING  
 2 = 4+2 ADEMCO L/S STANDARD 8 = 3+1, 4+1 ADEMCO L/S EXPANDED  
 3 = 4+2 RADIONICS STANDARD 9 = 3+1, 4+1 RADIONICS EXPANDED

- \*45 PHONE SYSTEM SELECT †  If Cent. Sta. IS NOT on a WATS line: [0 = Pulse Dial]; 1 = Tone Dial  
 If Cent. Sta. IS on a WATS line: 2 = Pulse Dial; 3 = Tone Dial
- \*46 SESCOA/RADIONICS SELECT †  [0 = Radionics (0-9, B-F reporting)]; 1 = SESCOA (0-9 only reporting)  
 Select 0 for all other formats.
- \*47 15 SEC DIALER DELAY (BURG) †  [0 = no], 1 = yes
- \*48 24 HR TEST MESSAGE †  [0 = no], 1 = yes (enter Test Code in field \*64)

- \*49 SPLIT/DUAL REPORTING  [0 = Backup report only]
- |     | TO PRIMARY PHONE No.         | TO SECONDARY PHONE No. |
|-----|------------------------------|------------------------|
| 1 = | Alarms, Restore, Cancel      | Others                 |
| 2 = | All except Open/Close, Test  | Open/Close, Test       |
| 3 = | Alarms, Restore, Cancel      | All                    |
| 4 = | All except Open, Close, Test | All                    |
| 5 = | All                          | All                    |

† Entry of a number other than one specified will give unpredictable results.

OVER →

**ALARM REPORT CODES (\*50-\*59)**

- \*50 1st DIGIT OF Zn 95 (left), Zn 96 (right)    
 Enter 1-9, 0, B-F as described in box below.  
 A "0" (not #+10) will disable report.  
 2nd Digit of each (for expanded or 4+2 reporting)  
 is same as for field \*57.  
 Zone 95 is Silent Panic (Key A or 1&#\*);  
 Zone 96 is Audible Panic (Key C or 3&#\*).

**TO PROGRAM REPORT CODES FOR ALARM, SYSTEM STATUS, RESTORE, & XMTR IDs(\*55-\*91):**

With a 3+1 or 4+1 Standard Format: Enter a code in the first box; 1-9, 0, B, C, D, E, or F. Enter [#+10] for 0, [#+11] for B, [#+12] for C, [#+13] for D, [#+14] for E, [#+15] for F.

A [0] (not [#+10]) in the first box will disable a report.

A [0] (not [#+10]) in the second box will result in automatic advance to the next field when programming.

With an Expanded or 4+2 Format: Enter codes in both boxes (1st and 2nd digits) for 1-9, 0, or B-F, as described above.

A [0] (not [#+10]) in the second box will eliminate the expanded message for that report.

A [0] (not [#+10]) in both boxes will disable the report.

With Ademco Contact ID Reporting: Enter any digit (other than [0]) in the first box, to enable zone to report (entries in the second boxes will be ignored).

A [0] (not [#+10]) in the first digit box will disable the report.

Examples: For Code 3 (Single Digit), enter:  3  0

For Code 32 (Two Digits), enter:  3  2

For Code B2 (Hexadecimal) enter:  #+11  2

- \*55 ZONE 5 ALARM REPORT CODE
- \*56 ZONE 6 ALARM REPORT CODE
- \*57 ZONE 7 ALARM REPORT CODE    
 (Console Panic: Key B or \*&#\*)
- \*58 ZONE 8 ALARM RPT CODE (Duress)
- \*59 ZONE 9 ALARM RPT CODE (Tamper)

**SYSTEM STATUS REPORT CODES (\*60-\*68)**

- \*60 TROUBLE REPORT CODE
- \*61 BYPASS REPORT CODE
- \*62 AC LOSS REPORT CODE
- \*63 LOW BAT REPORT CODE
- \*64 TEST REPORT CODE
- \*65 OPEN REPORT CODE
- \*66 CLOSE REPORT CODE

†† 2nd digit is automatically sent as the user number if expanded or 4+2 reporting is selected.

- \*67 RF XMTR LOW BAT RPT CODE
- \*68 CANCEL REPORT CODE

**RESTORE REPORT CODES (\*69-\*75)**

- \*69 GROUP RESTORES for TROUBLE, RF LOW BATTERY, BYPASS   
 [0 = no (report for each restore),  
 1 = yes (report after all zones restored)  
 Note: "1" not applicable to Contact ID reporting.
- \*70 ALARM RESTORE REPORT CODE   
 2nd digit is automatically sent as the 2nd digit of the zone alarm report code programmed in \*50-\*59 and \*76-\*91, if expanded or 4+2 reporting is selected.
- \*71 TROUBLE RESTORE REPORT CODE
- \*72 BYPASS RESTORE REPORT CODE
- \*73 AC RESTORE REPORT CODE
- \*74 LOW BAT RESTORE REPORT CODE
- \*75 RF XMTR LO BAT RSTR RPT CODE

**RF XMTR IDs/REPORT CODES (\*76-\*92)**

When Using ↓ ↓ These Fields are Programmable

4281L \*76-\*79 plus \*92

4281M \*76-\*83 plus \*92

4281H \*76-\*92

RF XMTR ID	Zone Type	RF XMTR ID	Zone Type
10-13	ENTRY/EXIT, Burg.	48-55	FIRE
14-29	PERIMETER, Burg.	56-61	TROUBLE BY DAY/
30-43	INT/FOLLOWER, Burg.		ALARM BY NITE, Burg.
44, 45	INT w/DELAY, Burg.	62	24 hr. (audible)
46, 47	PERIMETER, Burg.	63	Programmed by field *92

**RF XMTR ID / Report Code**

- \*76 1st Transmitter ID   /   Rpt Code
- \*77 2nd Transmitter ID   /   Rpt Code
- \*78 3rd Transmitter ID   /   Rpt Code
- \*79 4th Transmitter ID   /   Rpt Code
- \*80 5th Transmitter ID   /   Rpt Code
- \*81 6th Transmitter ID   /   Rpt Code
- \*82 7th Transmitter ID   /   Rpt Code
- \*83 8th Transmitter ID   /   Rpt Code
- \*84 9th Transmitter ID   /   Rpt Code
- \*85 10th Transmitter ID   /   Rpt Code
- \*86 11th Transmitter ID   /   Rpt Code
- \*87 12th Transmitter ID   /   Rpt Code
- \*88 13th Transmitter ID   /   Rpt Code
- \*89 14th Transmitter ID   /   Rpt Code
- \*90 15th Transmitter ID   /   Rpt Code
- \*91 16th Transmitter ID   /   Rpt Code
- \*92 ZONE RESPONSE OF XMTR ID 63 (if used)   
 Only zone types [0], 6, 7, 8, 9 applicable.

**DOWNLOAD INFO (\*94-\*97)**

\*94 DOWNLOAD PHONE No.

Enter up to 12 digits, 0-9. Do not fill unused spaces. If fewer than 12 digits entered, exit field by pressing \* (and press 95, if entering next field). To clear entries from field, press \*94\*.

- \*95 RING DET COUNT FOR DOWNLOADING   
 [0=Disable Station Initiated Download]; 1-14=number of rings (1-9, #+10=10, #+11=11, #+12=12, #+13=13, #+14=14); 15=answering machine defeat (#+15=15)
- \*96 INITIALIZES DOWNLOAD ID, SUBSCRIBER ACCOUNT No. FOR INITIAL DOWNLOAD  
 No entry required.
- \*97 ZEROS ALL PROGRAM FIELDS  
 No entry required.

**TO EXIT PROGRAM MODE (\*98 or \*99)**

Press \*98 or \*99 if exiting programming, or next field number if continuing.

- \*98 EXITS PROGRAMMING MODE and prevents re-entry by: Master Code + Code + 0.
- \*99 EXITS PROGRAMMING MODE and allows re-entry by: Master Code + Code + 0.